




What's in the box ?

- Yang ada di dalam kotak?



Customer service information

Informasi Layanan Pelanggan

Hotline : 0859-59 11 33 22

www.wikomobile.com



THANK YOU!
TERIMA KASIH!
MERCI!

Wiko SAS





1, rue Capitaine Dessemond - 13007 Marseille - France

Tel +33 4 88 08 95 15 | Fax +33 4 88 08 95 20

wikomobile.com | SIRET 530 072 206 00028 - APE 4652Z

First steps

- Langkah pertama



Wiko
Game changer.

robby 2



- Quick start guide • Panduan Cepat

Diproduksi oleh : PT. Tridharma Kencana
Serang – Indonesia